
# Cartridge and Immersion Temperature Controllers


17000/18000 Series Starts at

**\$210** 



- Cartridge and Hex Head Immersion (17000 Series)
- ✓ Coupling Head Immersion (18000 Series)
- ✓ Non-Indicating
- √ -73 to 316°C (-100 to 600°F) Temperature Range
- ✓ Slow Make and Break SPST
- ✓ -17.7°C (0.1°F) Accuracy
- Not Recommended for Pilot Duty Switching of Mechanical Contactor







#### **Application**

Cartridge type is designed for drilled hole cartridge heating installations in molding presses, platens, rubber vulcanizers, hot plates, etc.

#### **Features**

- Adjustable range from -73 to 316°C (-100 to 600°F) offers wide field of application
- Resolution sensitivity of -17.7°C (0.1°F) offers close control of process
- Compact size; lengths under 127 mm (5") and diameters less than 20.6 mm (½") fit almost any application
- Fast response as external metal shell expands or contracts with each temperature change
- Sheathing is brass for low range units; stainless steel for higher temperature use
- Couplings for hex head and coupling head types are brass with standard pipe threads for mounting. Hex head and coupling head immersion types are screwed directly through the threaded opening in tank or duct or directly into a pipeline containing gas or liquid. The coupling head unit may be directly attached to electrical conduit by means of standard male pipe threads.





#### MOST POPULAR MODELS HIGHLIGHTED!

To Order (Specify Model Number)										
		Temperature	Contact Operating/	Max An	nps AC	Dimension	ns: mm (in)	Wt		
Model No.	Price	Range °C (°F)	Temp Rise	120V	240V	Α	В	oz (lb)		
Cartridge Type										
17000-0	\$210	-73 to 204 (-100 to 400)	Opens	10	5	94 (3.72)	16 (0.625)	32 (2)		
17021-0	210	-73 to 204 (-100 to 400)	Closes	10	5	94 (3.72)	16 (0.625)	32 (2)		
17002-0	260	-73 to 315 (-100 to 600)	Opens	10	5	94 (3.72)	16 (0.625)	32 (2)		
17023-0	260	-73 to 315 (-100 to 600)	Closes	10	5	94 (3.72)	16 (0.625)	32 (2)		
17052-0	285	-73 to 315 (-100 to 600)	Opens	25	12.5	94 (3.72)	20 (0.81)	48 (3)		
Hex Head Immersion Type (With Knob and Dial)										
17100-0	\$285	-73 to 204 (-100 to 400)	Opens	10	5	109 (4.28)	16 (0.625)	80 (5)		
17121-0	285	-73 to 204 (-100 to 400)	Closes	10	5	109 (4.28)	16 (0.625)	80 (5)		
17102-0	350	-73 to 315 (-100 to 600)	Opens	10	5	109 (4.28)	16 (0.625)	80 (5)		
17123-0	350	-73 to 315 (-100 to 600)	Closes	10	5	109 (4.28)	16 (0.625)	80 (5)		
17152-0	400	-73 to 315 (-100 to 600)	Opens	25	12.5	119 (4.68)	20 (0.81)	128 (8)		
Coupling Head Immersion Type										
18000-0	\$290	-73 to 204 (-100 to 400)	Opens	10	5	118 (4.65)	16 (0.625)	80 (5)		
18021-0	320	-73 to 204 (-100 to 400)	Closes	10	5	118 (4.65)	16 (0.625)	80 (5)		
18002-0	320	-73 to 315 (-100 to 600)	Opens	10	5	118 (4.65)	16 (0.625)	80 (5)		
18023-0	320	-73 to 315 (-100 to 600)	Closes	10	5	118 (4.65)	16 (0.625)	80 (5)		

Note: All models are UL recognized

Important: Connect 0.1 µf capacitor across switch leads on all 240 Vac applications.

Ordering Examples: 17100-0, immersion temperature controller, \$210.

18000-0, coupling head immersion type, \$290.

## Hazardous Location Immersion Temperature Controller


80000 Series Starts at

\$14**50** 



- Explosion Resistant Junction Box
- Non-Indicating
- Heliarc Welded Thermowell
- ✓ Tolerates Extreme 
  Temperature Exposures
- ✓ 10 Amps at 120 Vac, 5 Amps at 240 Vac

The 80016 is an assembly consisting of a series 17000 or 47000 model, well assembly, and explosion-resistant junction box designed to meet the requirements of Class I, Group D, and Class II, Group E, F and G, Division 1 and 2 locations. The sensing element, which is a cartridge-type unit, is seated in the well assembly, and held in place by a snap ring. The well assembly, in turn, is threaded into the explosion-resistant junction box, giving protection to the controller. Not recommended for pilot duty switching of magnetic contactors.



#### **Specifications**

Well Assembly Pressure Ratings: 690 kPa at 120°C (100 psi at 250°F) 415 kPa at 260°C (60 psi at 500°F)

Well Assembly Material: Type 321 stainless steel

Current Rating: 10 A at 120 Vac;

5 Amps at 240 Vac Extreme Temperature Exposures:

May be exposed to -74°C (-100°F) indefinitely; they may be exposed to high temperature for one hour maximum, refer to the chart.

Model No.	Temp. Exposure
80016-17000	100°F (55°C)
	above setpoint
80016-17021	500°F (260°C)
80016-47002	100°F (55°C)
	above setpoint
80016-47023	600°F (315°C)

WARNING: Hazard of Fire.
These controls function as temperature controls only. Because they do not fail-safe an approved temperature and/or pressure safety control must be used for safe operation.



80016-17000, \$961, shown larger than actual size.

#### MOST POPULAR MODELS HIGHLIGHTED!

To Order (Specify Model Number)							
Model No.	Price	Temperature Range	Contact Operation on Temperature Rise				
80016-17000	\$1450	-74 to 204°C (-100 to 400°F)	Opens				
80016-17021	1450	-74 to 204°C (-100 to 400°F)	Closes				
80016-47002	1560	-74 to 260°C (-100 to 500°F)	Opens				
80016-47023	1560	-74 to 260°C (-100 to 500°F)	Closes				

Ordering Example: 80016-17000, immersion temperature controller, \$1450.

## omega.co.uk®

Your One-Stop Source for Process Measurement and Control!

#### www.omega.co.uk



#### UNITED STATES

www.omega.com 1-800-TC-OMEGA Stamford, CT.

#### **CANADA**

www.omega.ca Laval(Quebec) 1-800-TC-OMEGA

#### **GERMANY**

www.omega.de Deckenpfronn, Germany 0800-8266342

#### **UNITED KINGDOM**

Freephone 0800 488 488 | International +44(0) 161 777 6622 | Fax +44(0) 161 777 6622

www. omega.co.uk Manchester, England 0800-488-488 +44-(0)161-777-6611

#### **FRANCE**

www.omega.fr 0800-466-342

#### **BENELUX**

www.omega.nl 0800-099-33-44



Sales@omega.co.uk

### More than 100,000 Products Available!

#### Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

#### Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

#### pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

#### Data Acquisition

Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485, Ehernet and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

#### Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

#### Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters