# **Epoxies and Thermally Conductive Pastes**

OMEGABOND™ epoxy and OMEGATHERM™ thermal conducting paste are high temperature and high thermally conductive epoxies and silicone products. They are specially formulated for permanent and temporary bonding of thermocouples, thin film RTDs, thermistors and other temperature sensors, to most surfaces-metals, ceramics, glass, plastics, paper products.

OMEGABOND™ and OMEGATHERM™ products are compounded and packaged for convenient, easy mixing and application. Each formulation exhibits important characteristics necessary for accurate, fast, reliable temperature measurement. These are: good adhesion and strength, high temperature rating, high thermal conduction, high electric insulation, thixotropic consistency, fast cure, and easy application.

To assist in your selection, a summary of each product's properties is shown in the accompanying table.

"Twin pak" packaging is supplied to ensure the user with accurate proportioning of resin and catalyst, as well as to provide a clean, fast means of mixing. The "Twin Pak" is a flexible, transparent plastic pouch, separated into two isolated compartments by means of a removable external divider. In one compartment is the resin, the other the premeasured catalyst. To use, remove the divider, mix the two components by kneading the pouch, then snip off a corner to dispense. Each "Twin Pak" comes with an instruction sheet, enclosed in a clear, heat-sealed plastic envelope.

### **Typical Properties**

Model No.	OB-100	OB-101	OB-200	OT-201
Material	Fast Set Epoxy Adhesive	Epoxy Adhesive	Epoxy Adhesive	Silicone Grease
Max. Continuous Temperature	130°C (265°F)	105°C (221°F)	260°C (500°F)	200°C (392°F)
Cure	8–12 min. set Room Temp.	Room Temp.	Elevated Temp.	Not required
Adheres to	M, C, PL,	M, C, PL,	M, C, PL,	Wets
Most*	PA, W	PA, W	PA, W	most Surfaces
Thermal conductivity (k)	Low	High	Very High	Extremely
(BTU) (in)/(hr) (ft²) (°F)		7.2	9.6	High 16
Electrical Insulation Volume Resistivity ohm–cm	High 10 <sup>12</sup>	Very High 10 <sup>15</sup>	Very High 10 <sup>15</sup>	Very High 10 <sup>14</sup>
Tensile Shear PSI MIN	2000	2200	2700	_
Flexure Strength PSI MIN		12,000	17,000	
Coefficient of Thermal Expansion in/in/°F	51 x 10 <sup>-6</sup>	20 x 10 <sup>-6</sup>	21 x 10 <sup>-6</sup>	

PA = Paper Products

W = Wood

The above information, while determined by tests and evaluation, is offered only as a general guide. Actual suitability for a particular purpose must be determined by material user. This information is not to be taken as a warranty for which we assume legal responsibility.



# OMEGABOND™ 100

OMEGABOND™ 100 — a fast (8 to 12 minute setting time), room temperature, two-part epoxy. Recommended for easy temporary and permanent bonding of beaded wire and "cement-on" thermocouples. Adheres to metals, ceramics, epoxy laminates, glass, wood, concrete and many other materials—for temperature measurements up to 129°C (265°F). It is not recommended for those endeavoring to achieve the ultimate in precision and speed of response, since this unfilled system has a relatively low thermal conductivity.

Temporary installation of beaded wire thermocouples can be achieved by using a very small amount of OMEGABOND™ 100 to tack the bead to the surface and packing OMEGATHERM™ 201 around the exposed surface to improve heat transfer. This clear syrup consistency-100% solid adhesive — contains no solvents and has good strength and electrical insulation characteristics. Note: The working time after mixing the two-part system at room temperature is only 6 to 8 minutes. OMEGABOND 100 is available in "Twin Pak" packs and 450g and 900g kits.

### OMEGABOND™ 101

OMEGABOND™101—is a very versatile room-temperature curing, highly thermally conductive, two-part epoxy adhesive designed specifically to bond permanently "cement-on" and beaded wire thermocouples and other sensors to the widest variety of materials. Adheres to most metals, wood, ceramics, cements, paper products, and many plastics and rubbers. It is rated for continuous use at 105°C (221°F). This thixotropic off-white paste will set up in approximately four hours at room temperature with full curing in 24 hours. Curing can be accelerated by applying moderate heat.

OMEGABOND™ 101 has excellent shear and tensile strength, high electrical insulation and excellent chemical and solvent resistance. It is supplied in convenient "Twin Pak" packs as well as 450g and 900g pound kits, and is easy to mix, apply and cure.

## OMEGABOND™ 200

OMEGABOND™ 200 — is a black, high temperature, high thermally conductive, two-part epoxy system which will bond sensors to most materials, including metals, glass, ceramics and most plastics. It is recommended for bonding of "cement-on" and beaded wire thermocouples for accuracy and fast temperature measurement to 260°C (500°F). This epoxy system cures at elevated temperatures. Curing time is 8 hours at 120°C (250°F), 2 hours at 205°C (400°F). It has excellent strength and electrical insulating characteristics. Its thixotropic paste consistency virtually ensures freedom from sag during curing when applied to vertical surfaces.



# OMEGATHERM™ 201

OMEGATHERM™ 201 — is a very high thermally conductive filled silicone paste, ideally suited for many temperature measurement applications. This thick, grey, smooth paste wets most surfaces and will not harden on long exposure to elevated temperatures. It is rated for continuous use between -40 and 200°C (-40 and 392°F).

OMEGATHERM™ 201 provides an excellent means of conducting heat and expanding the heat-path area from a surface to a temperature measurement sensor, thus increasing the speed of response and improving accuracy. Some applications are:

a) Surface Measurement Probes — dab a small amount

on the surface and push the sensor into this area.

b) Temporary bonding and encapsulating of temperature sensors — simply dab OMEGATHERM™ 201 onto the surface or in the cavity, plant the sensor in the paste, and tape to hold in place.

This highly versatile paste is supplied in 14g and 56g jars, as well as in 450g and 900g containers.

#### ALL MODELS AVAILABLE FOR FAST DELIVERY!

To Order (Specify Model Number)			
MODEL NO.	PRICE	PRICE DESCRIPTION	
OB-100-1/4	£8.40	OMEGABOND 100 epoxy, one 7g twin pak	
OB-100-1	10.00	OMEGABOND 100 epoxy, four 7g twin pak	
OB-100-16	33.50	OMEGABOND 100 epoxy, 227g resin, 227g catalyst kit	
OB-101-1/2	3.40	OMEGABOND 101 epoxy, one 14g twin pak	
OB-101-2	8.00	OMEGABOND 101 epoxy, one 56g twin pak	
OB-101-16	37.50	OMEGABOND 101 epoxy, 227g resin, 450g catalyst kit	
OB-200-2	11.50	OMEGABOND 200 epoxy, one 56g twin pak	
OB-200-16	40.00	OMEGABOND 200 epoxy, 227g resin, 450g catalyst kit	
OT-201-1/2	10.00	Thermally conductive paste, 14g jar	
OT-201-2	16.75	Thermally conductive paste, 56g jar	
OT-201-16	101.00	Thermally conductive paste, 450g can	

#### **Multi-Purpose** OMEGABOND™ & OMEGATHERM™ Kit

This versatile kit is recommended as a convenient way to determine the best means to bond sensors before ordering in quantity. Each kit contains:

four — 7g "Twin Paks" of OMEGABOND™ 100 two — 14g "Twin Paks" of OMEGABOND™ 101 one — 56g "Twin Pak" of OMEGABOND™ 200 two — 14g Jars of OMEGATHERM™ 201

When ordering, specify "MPK-1" £50 per kit



# omega.co.uk®

Your One-Stop Source for Process Measurement and Control!

Freephone 0800 488 488 | International +44(0) 161 777 6622 | Fax +44(0) 161 777 6622 |

# www.omega.co.uk



# UNITED STATES www.omega.com

1-800-TC-OMEGA Stamford, CT.

#### **CANADA**

www.omega.ca Laval(Quebec) 1-800-TC-OMEGA

#### **GERMANY**

www.omega.de
Deckenpfronn, Germany
0800-8266342

## **UNITED KINGDOM**

www. omega.co.uk Manchester, England 0800-488-488 +44-(0)161-777-6611

#### **FRANCE**

www.omega.fr 0800-466-342

#### **BENELUX**

www.omega.nl 0800-099-33-44



Sales@omega.co.uk

# More than 100,000 Products Available!

## Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

### Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

# pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

# Data Acquisition

Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485, Ehernet and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

### Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

#### Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters