

NEW NORGREN EXCELON® FILTER-REGULATOR/LUBRICATOR **COMBINATION UNITS**

C72H Series Starts at







- True Modularity with Norgren Quikclamp® Connections
- Quick Release Bayonet Bowl
- Lubricator Flow Sensor Provides a Nearly Constant Oil/Air Ratio Over a Wide Range of Air Flows
- All Around (360°) Visibility of the Lubricator Sight-Feed **Dome Simplifies Installation** and Adjustment
- Regulator Balanced Valve Minimizes Effect of Variation in the Inlet Pressure on the **Outlet Pressure**

SPECIFICATIONS

Fluid: Compressed air **Maximum Pressure:**

Transparent Bowl: 10 bar (150 psig)

Metal Bowl:

Manual or Semiautomatic Drain: 17 bar (250 psig)

Automatic Drain: 10 bar (150 psig)

Operating Temperature*:

Transparent Bowl:
-20 to 50°C (0 to 125°F)
Metal Bowl: -20 to 65°C (0 to 150°F) Particle Removal: 5, 25, or 40 um

filter element


MATERIALS Body: Zinc

Bonnet: Acetal

Transparent Bowl: Polycarbonate **Guard for Transparent Bowl:** Zinc Metal: Zinc

Metal Bowl Liquid Level

Indicator Lens: Transparent nylon Sight Feed Dome: Transparent nylon **Element:** Sintered polypropelene Elastomers: Neoprene® and nitrile * Air supply must be dry enough to avoid ice formation at temperatures below 2°C (35°)F.



To Order (Specify Model Number)

MOST POPULAR MODELS HIGHLIGHTED!

MODEL NO.	PRICE	PORT SIZE (in)	COMBINATION TYPE	WEIGHT kg (lb)
C72H-2AK-AW3-RMG-QWN	\$147	1/4	Standard micro-fog filter/regulator with lubricator	1.08 (2.37)
C72H-3AK-AW3-RMG-QWN	146	3/8	Standard micro-fog filter/regulator with lubricator	1.08 (2.37)
C73H-2AK-AD3-RMG-QDN	203	3/8	Standard micro-fog filter/regulator with lubricator	1.36 (3.0)
C73H-3AK-AD3-RMG-QDN	203	3/8	Standard micro-fog filter/regulator with lubricator	1.36 (3.0)
C73H-4AK-AD3-RMG-QDN	203	1/2	Standard micro-fog filter/regulator with lubricator	1.36 (3.0)
C74H-3AK-AD3-RMG-QDN	238	3/8	Standard micro-fog filter/regulator with lubricator	2.36 (5.20)
C74H-4AK-AD3-RMG-QDN	238	1/2	Standard micro-fog filter/regulator with lubricator	2.30 (5.07)

Notes: Models include PTF threads. Filter/regulator has a knob adjustment, automatic drain, transparent bowl with guard, 40 µm element, relieving diaphragm and 10 bar (150 psig) regulating spring and gage. Lubricator is a micro-fog model with ½ turn manual drain and transparent bowl with guard.

Ordering Examples: C72H-2AK-AW3-RMG-QWN, combination filter-regulator and lubricator, includes a standard micro-fog filter/regulator with a 1/4" PTF port, knob pressure adjustment, automatic filter drain, 40 µm filter, relieving diaphragm, 5 to 150 psig regulating spring, manual ¼ turn drain and transparent lubricator bowl with guard, \$147. C72H-3AK-AW3-RMG-QWN, combination filter-regulator and lubricator, includes a standard micro-fog filter/regulator with a ¾" PTF port, knob pressure adjustment, automatic filter drain, metal filter bowl with liquid level indicator and 40 μm filter, relieving diaphragm, 5 to 150 psig regulating spring, manual ¼ turn drain and metal lubricator bowl with liquid level indicator, \$146.

omega.co.uk®

Your One-Stop Source for Process Measurement and Control!

www.omega.co.uk



UNITED STATES

www.omega.com 1-800-TC-OMEGA Stamford, CT.

CANADA

www.omega.ca Laval(Quebec) 1-800-TC-OMEGA

GERMANY

www.omega.de Deckenpfronn, Germany 0800-8266342

UNITED KINGDOM

Freephone 0800 488 488 | International +44(0) 161 777 6622 | Fax +44(0) 161 777 6622

www. omega.co.uk Manchester, England 0800-488-488 +44-(0)161-777-6611

FRANCE

www.omega.fr 0800-466-342

BENELUX

www.omega.nl 0800-099-33-44



Sales@omega.co.uk

More than 100,000 Products Available!

Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

Data Acquisition

Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485, Ehernet and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters