
OM-CP-PROCESS101 and OM-CP-PROCESS110 Process Current Data Loggers

Part of the NOMAD® Family






OM-CP-PROCESS101, £133 data logger shown larger than actual size

OM-CP-PROCESS110-25MA, £200, data logger shown larger than actual size

£**133** Basic Unit

- 16-Bit Resolution
- Programmable Scale Factor, Engineering Units and Offset Value
- Memory Wrap Around
- Miniature Size
- User Calibration Through Software
- Real Time Operation

The OM-CP-PROCESS101 and OM-CP-PROCESS110 are low cost, high resolution, miniature battery powered, stand-alone data loggers used for automatically recording current. In addition, these data loggers allow the user to store user defined units such as pressure into the device as well as scale factors and offset values. This enables the user to easily linearise and scale any process meter that provides an analogue output to engineering units automatically. This all-in-one compact, portable, easy-to-use device will measure and record up to 32,768 current measurements.



OM-CP-IFC110, £66, Windows software displays data in graphical or tabular format.

These data loggers are a major leap forward in both size and performance. Its real time clock ensures that all data is time and date stamped.

The storage medium is non-volatile solid state memory, providing maximum data security even if the battery becomes discharged. Its small size allows it to fit almost anywhere. Data retrieval is simple. Plug it into an empty COM port and our easy to use software does the rest. The software converts your PC into a real time strip chart recorder. Data can be printed in graphical or tabular format and can be exported to a text or Microsoft Excel file.

TH Date Time

Image: state of the s

Statistics

Maximum

Average

Standard Deviation

20.01 mA

10.9327 mA

5.40783 m4

Specifications

Input Connection: Screw terminal ADC Resolution: 16-bits Current Calibration: Digital calibration is available in software Recording Interval: 1 second to 12 hours selectable in software Real Time Recording: Device may be used with PC to monitor and record data in real time Red Visual Indicator: LED flashes at selected reading rate



OM-CP-PROCESS101, £133, data logger shown larger than actual size

Power:

3.6 V lithium battery included Battery Life: OM-CP-PROCESS101: 1 year at 1 min reading rate OM-CP-PROCESS110: 10 years at 15 min reading rate Time Accuracy: ±1 minute per month at 20°C

Data Format: Date and time stamped, volts, other engineering units programmable through software

Weight:

OM-CP-PROCESS101: 30 g (1 oz) OM-CP-PROCESS110: 60 g (2 oz) **Computer Interface:** PC serial, RS-232C COM or USB (interface cable required) Software: Windows 95/98/NT/2000/XP **Communications:** OM-CP-PROCESS101: 2400 baud OM-CP-PROCESS110: 57600 baud



OM-CP-PROCESS110-1MA, £133 data logger shown larger than actual size

Operating Environment: -40 to 80°C (-40 to 176°F) 0 to 95% RH non-condensing Dimensions: OM-CP-PROCESS101: 35 H x 64 W x 15 mm D (1.4 x 2.5 x 0.6") OM-CP-PROCESS110: 41 H x 58 W x 20 mm D (1.6 x 2.3 x 0.8")

INPUT RANGES	OM-CP-PROCESS101	OM-CP-PROCESS110-1MA	OM-CP-PROCESS110-25MA	OM-CP-PROCESS110-100MA
Nominal Input Range	0 to 100 mA	±1 mA	±25 mA	±100 mA
Measurement Range	-20 to 120 mA	±1.25 mA	±30mA	±120 mA
Resolution	10 µA	0.05 <i>µ</i> A	1 µA	5 µA
Accuracy	±0.1% FSR	±0.5% FSR	±0.1% FSR	±0.1% FSR
Input Impedance	10 Ω	50 Ω	10 Ω	2 Ω
Overload Protection	±125 mA	±20 mA	±100 mA	±125 mA

MOST POPULAR MODELS HIGHLIGHTED!

To Order (Specify Model Number)				
Model No.	Price	Description		
OM-CP-PROCESS101	£133	Process input data logger, 0 to 100 mA input range		
OM-CP-PROCESS110-25MA	200	Process input data logger, ± 25 mA input range, extended battery life		
OM-CP-PROCESS110-1MA	200	Process input data logger, ±1 mA input range, extended battery life		
OM-CP-PROCESS110-100MA	200	Process input data logger, ± 100 mA input range, extended battery life		
OM-CP-IFC110	66	Windows software and 1.2 m (4') RS-232 cable with DB9F termination		
OM-CP-IFC200	80	Windows software and 3.7 m (12') USB interface cable		
OM-CP-BAT105	8	Replacement 3.6 V lithium battery		
CAL-3-HH	50	Traceable calibration certificate with test results		
OM-CP-CONNECTOR-2	3	Replacement 2 position terminal block connector for the OM-CP-PROCESS101		
OM-CP-CONNECTOR-3	4	Replacement 3 position terminal block connector for the OM-CP-PROCESS110-1MA, OM-CP-PROCESS110-25MA and OM-CP-PROCESS110-100MA		

Operator's manual, battery, and RS-232 cable are included with the **OM-CP-IFC110** Windows software, (software is required to operate the data logger and is sold separately).

Ordering Example: OM-CP-PROCESS101 4 to 20 mA current data logger and OM-CP-IFC200 Windows software and USB cable, £133 + 66 = £199

omega.co.uk®

Your One-Stop Source for Process Measurement and Control!

Freephone 0800 488 488 | International +44(0) 161 777 6622 | Fax +44(0) 161 777 6622

Sales@omega.co.uk

www.omega.co.uk



UNITED STATES www.omega.com 1-800-TC-OMEGA Stamford, CT.

CANADA www.omega.ca Laval(Quebec) 1-800-TC-OMEGA

GERMANY www.omega.de Deckenpfronn, Germany 0800-8266342

UNITED KINGDOM www.omega.co.uk Manchester, England 0800-488-488

> FRANCE www.omega.fr 088-466-342

CZECH REPUBLIC www.omegaeng.cz Karviná, Czech Republic 596-311-899

> BENELUX www.omega.nl 0800-099-33-44



More than 100,000 Products Available!

Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

Data Acquisition

Auto-Dialers and Alarm Monitoring Systems, Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485 and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters