OM-CP-THERMOVAULT Oven Temperature Data Logger

Part of the NOMAD® Family





✓ Single Channel Thermocouple Input

Programmable Start Time; Immediate or Date/Time

Miniature Size

Record Short Thermal **Profiling Events**

The OM-CP-THERMOVAULT is a thermally insulated, batterypowered, stand-alone data logger used for thermal profiling of events. This device can be used to record the temperature inside an oven for later downloading to a PC. This allin-one, compact, portable, easy-touse device will measure and record up to 16,383 temperature measurements. It can withstand an oven temperature of 752°F for 10 minutes when properly sealed. The OM-CP-THERMOVAULT is a major leap forward in both cost reduction and performance. Its real-time clock ensures that all data is time and date stamped. The storage medium is non-volatile solid state memory, providing maximum data security even if the battery becomes discharged. The thermovault's small size allows it to fit almost anywhere. Data retrieval is simple. Plug it into an available COM port and our easy-to-use software does the rest. The software converts your PC into a real-time strip chart recorder. Data can be printed in graphical or tabular format and can be exported to a text or Microsoft Excel file.

Specifications

Thermocouple Connection:

Fixed 2 position screw terminal **Cold Junction Compensation:**

Automatic

Accuracy* (based on internal channel at uniform 20°C):

J, K, T, E, N: ±0.5°C **R**, **S**, **B**: ±2.5°C

Resolution:

J, K, T, E, N: 0.1°C R, S, B: 0.5°C

Memory: 16,383 readings/channel

Temperature Measurement Range: Type

J: -210 to 760°C **K**: -270 to 1370°C

T: -270 to 400°C E: -270 to 980°C

R: -50 to 1760°C S: -50 to 1760°C

B: 50 to 1820°C N: -270 to 1300°C

Recording

Interval: 2 seconds to 12 hours selectable

in software

Start Time: Start time and date are programmable through software

Power: 3.6 V lithium battery included

Battery Life: 1 year typical Data Format: Date and time stamped, °C, °F, °K, °R, mV

Computer Interface: PC serial, RS-232C COM or USB Software:

WIN98/NT/2000/XP/VISTA 32-bit

(VISTA 32-bit version only; VISTA 64-bit is not supported) Operating Environment for Internal Data Logger:

-40 to 80°C (-40 to 176°F) 0 to 95% RH non-condensing Operating Environment for

OM-CP-THERMOVAULT System:

-40 to 400°C (-40 to 752°F) 0 to 95% RH non-condensing **Dimensions:** 76 H x 153 L x 102 mm D

 $(3 \times 6 \times 4")$

Weight: 0.9 kg (2 lbs)

Enclosure (Thermal Box): Thermal insulators encased in stainless steel Enclosure (Logger): ABS Plastic

data logger, \$999, shown smaller than actual size **Maximum Exposure Temperature vs Duration Ambient Max Duration** Temp °C (°F) in Minutes** 100 (212) 52 150 (302) 30 200 (392) 22 250 (482) 17 260 (500) 16 300 (572) 15 350 (662) 12 400 (752) 10

OM-CP-IFC110, \$99. Windows software

graphical or tabular format

OM-CP-THERMOVAULT

displays data in

* Accuracy does not include errors due to thermocouple.

** Assuming logger box is initially at 25°C.

AVAILABLE FOR FAST DELIVERY!

To Order (Specify Model Number)		
Model No.	Price	Description
OM-CP-THERMOVAULT	\$999	Oven temperature data logger
OM-CP-THERMOVAULT-CERT	1059	Oven temperature data logger with NIST calibration certificate
OM-CP-IFC110	99	Windows software and 1.2 m (4') RS-232 cable with DB9F termination
OM-CP-IFC200	119	Windows software and 3.7 m (12') USB interface cable
OM-CP-BAT105	12	Replacement 3.6 V lithium battery

Operator's manual, battery and RS-232 cable are included with the **OM-CP-IFC110** Windows software (required to operate the data logger) is sold separately. **Ordering Example: OM-CP-THERMOVAULT-CERT,** oven temperature data logger with NIST calibration certificate, **OM-CP-IFC110,** Windows software and RS-232 cable, \$1059 + 99 = \$1158.

omega.co.uk®

Your One-Stop Source for Process Measurement and Control!

Freephone 0800 488 488 | International +44(0) 161 777 6622

Fax +44(0) 161 777 6622

Sales@omega.co.uk

www.omega.co.uk



UNITED STATES

www.omega.com 1-800-TC-OMEGA Stamford, CT.

CANADA

www.omega.ca Laval(Quebec) 1-800-TC-OMEGA

GERMANY

www.omega.de Deckenpfronn, Germany 0800-8266342

UNITED KINGDOM

www. omega.co.uk Manchester, England 0800-488-488

FRANCE

www.omega.fr 088-466-342

CZECH REPUBLIC

www.omegaeng.cz Karviná, Czech Republic 596-311-899

BENELUX

www.omega.nl 0800-099-33-44



More than 100,000 Products Available!

Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

Data Acquisition

Auto-Dialers and Alarm Monitoring Systems, Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485 and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters