HIGH VISCOSITY DRUM PUMPS

> FPUD500 Pump Motors Starts at

> > \$819



- Pump Tube and Motor Supplied Separately for Maximum Flexibility
- 316 SS or Sanitary Polished 316 SS Pump Tubes Available
- TEFC or Air Driven Motors
- ✓ For Fluids up to15,000 cps Viscosity and1.8 Specific Gravity

OMEGA® FPUD500 Series high viscosity drum pumps can empty a wide variety of containers in various applications. The pump tube and motor are constructed modularly and supplied separately for maximum flexibility.

Motor types available are 115 or 230 Vac, continuous duty, totally-enclosed fan-cooled (TEFC); and air driven. All motors listed as 115 Vac can be rewired for 230 Vac operation; all motors listed for 230 Vac can be rewired for 208 or 460 Vac operation. The Hz rating and number of phases CANNOT be changed in the field.

All Vac powered units include a 3.6 m (12'), three-wire cord and built-in ON/OFF switch.

The FPUD531 air motor has a ¼" female end fitting, while the FPUD532 and FPUD533 air motors have a ½" female end fitting for hooking up to a customer-supplied air hose, and includes a regulator valve and muffler. An optional air lubricator/filter assembly is also available if your air source is not filtered and lubricated.

When pumping flammable or combustible materials, or working in explosive environments, use an air motor with a stainless steel tube and FPUD5-SK static protection kit.




FPUD5 Series pump tubes are rated up to 93.3°C (200°F), 15,000 cps viscosity and 1.8 specific gravity. Refer to the performance curve graph for flow rate vs. discharge head data. See Section T for tubing.

All pump tubes have graphite-PTFE seals with PTFE internals. Outlet connections are 38 mm (1½") ID hose.

CAUTION: DO NOT USE
AN AIR MOTOR WITHOUT
THE FPUD5-SK STATIC
PROTECTION KIT

#### **Performance Curves**



#### **Pump Motors**

## **CUSTOM MODELS BUILT TO ORDER!**

To Order (Specify Model Number)								
Model No.	Price	НР	RPM	Power	Phase	Hz	Туре	Weight kg (lb)
FPUD511	\$1166	1	3450	115/230 Vac	1	60	TEFC/CSA	23.2 (51)
FPUD512*	1251	2	1725	115/230 Vac	1	60	TEFC/CSA	40.5 (89)
FPUD513*	1405	3	1725	115/230 Vac	1	60	TEFC/CSA	46.3 (102)
FPUD521	1166	1	3450	230/460 Vac	3	60	TEFC/CSA	15.9 (35)
FPUD524	1251	2	1725	230/460 Vac	3	60	TEFC/CSA	25.0 (55)
FPUD525*	1401	3	1725	230/460 Vac	3	60	TEFC/CSA	36.8 (81)
FPUD531	819	1	3000	air motor 100 psi @ 70 cfm	N/A	N/A	N/A	9.6 (21)
FPUD532	1141	2	3000	air motor 100 psi @125 cfm	N/A	N/A	N/A	12.7 (28)
FPUD533	1378	3	2500	air motor 100 psi @70 cfm	N/A	N/A	N/A	18.6 (41)

<sup>\*</sup> Too heavy for UPS shipment; use other motor freight.

FPUD5-S40, 316SS pump tube, \$1067, shown smaller than actual size.

### **Accessories for Pump Motors**

Model No.	Price	Description		
FPUD345-FL	\$165	Filter-lubricator assembly for FPUD531		
FPUD53-FL	404	Filter-lubricator assembly for FPUD532/533		
FPUD5-SK	441	Anti-static kit for air motors		



To Order (Specify Model Number)					
Model No.	Price	Tube OD	Tube Length m (ft)	Shipping Weight kg (lb)	
FPUD5-S40	\$1067	2"	1.0 (3.3)	5.0 (11)	

#### **Accessories for Pump Tube**

Model No.	Price	Description		
FPUD5-SS	\$71	316 stainless steel inlet strainer		
FPUD5-PDA	67	2" IPS polypro drum adaptor		
FPUD5-SDA	176	2" IPS 316 SS drum adaptor		
FPUD5-GDA	44	2" IPS galvanized steel drum adaptor		

Accessory

Accessory							
Model No.	Price	Description					
FW-0107	\$78	Reference Book: Chemical Engineering Fluid Mechanics					

Comes complete with operator's manual. AC powered pumps also include power cord.

Ordering Examples: FPUD532, air motor, FPUD5-SK anti-static kit, and FPUD5-S40, pump tube, \$1141 + 441 + 1067 = \$2649. FPUD511, 115 Vac motor, FPUD5-S40, 316 SS tube, \$1166 + 1067 = \$2233.







# omega.co.uk®

Your One-Stop Source for Process Measurement and Control!

# www.omega.co.uk



# UNITED STATES

www.omega.com 1-800-TC-OMEGA Stamford, CT.

#### **CANADA**

www.omega.ca Laval(Quebec) 1-800-TC-OMEGA

#### **GERMANY**

www.omega.de Deckenpfronn, Germany 0800-8266342

## **UNITED KINGDOM**

Freephone 0800 488 488 | International +44(0) 161 777 6622 | Fax +44(0) 161 777 6622

www. omega.co.uk Manchester, England 0800-488-488 +44-(0)161-777-6611

#### **FRANCE**

www.omega.fr 0800-466-342

#### **BENELUX**

www.omega.nl 0800-099-33-44



Sales@omega.co.uk

# More than 100,000 Products Available!

## Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

### Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

## pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

## Data Acquisition

Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485, Ehernet and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

## Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

#### Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters