

6:1 TURN-DOWN INDUSTRIAL DIFFERENTIAL PRESSURE TRANSMITTER

PX771A Series
4 to 20 mA Output
0-17 inH₂O to 0-300 psid

\$1005
All Models



PX771A-025DI, \$1005, shown smaller than actual size.



PX771A transmitter, shown with iSeries strain and process meters and controllers featured on page D-7, which start at \$150 and are shown smaller than actual size.

- ✓ 2-Year Warranty
- ✓ 0.15% FS Accuracy
- ✓ Explosion-Proof Electrical Housing
- ✓ Stainless Steel Wetted Parts


- ✓ Process Wetted Parts Meet NACE Specification MR0175-91
- ✓ High Common-Mode Pressure Rejection
- ✓ 6:1 Turn-Down Capability
- ✓ ±600% Zero Suppression or Elevation
- ✓ NEMA 4X (IP66) Housing
- ✓ 4 to 20 mA or 1 to 5 Vdc Output

The OMEGA® PX771A low-power pressure transmitter is a compact, high-performance unit, designed to measure differential pressure and transmit a 4 to 20 mA signal. It has an adjustable range with a turn-down ratio of 6:1, and it comes factory-calibrated at the highest span. Ranges from 17 inH₂O to 300 psid are available. Zero and span adjustments are accessed inside the electronic housing. The zero point can be elevated and suppressed up to ±600%. This transducer has an internal silicon diaphragm into which piezoresistive strain gages are diffused, then interconnected to form a pressure sensitive Wheatstone bridge.

FOR GAGE, DIFFERENTIAL, AND VACUUM MEASUREMENTS



Optional PX771-AD, 1/2 NPT adaptors, \$90 each. Shown smaller than actual size.



DIFFERENTIAL PRESSURE TRANSDUCERS **B**

SPECIFICATIONS

Service: Liquid, gas or vapor

Excitation:

24 Vdc, 7 to 36 Vdc mA output, 6 to 42 Vdc @ 1.6 mA voltage output

Output: 4 to 20 mA (2 wire) or 1 to 5 Vdc (3 wire) jumper selectable

Max Loop Resistance:

(Supply voltage – 7) x 50 Ω

Accuracy: ±0.1% of URL

(upper range limit, includes linearity, hysteresis and repeatability)

Stability: ±0.25% of URL

(upper range limit) 1 year

Span Adjust: 16 to 100% URL

(DIP switches and pot)

Zero Adjust: -600 to 600% LRL

(lower range limit)

Operating Temperature:

Process: -40 to 104°C (-40 to 220°F)

Electrical: -32 to 85°C (-25 to 185°F)

Ambient Total Thermal Effects:

0.010% URL/°F for -25 to 75°F

0.015% URL/°F for 75 to 185°F

(0.020% URL/°F for 100 inH₂O)

Response Time: 63% response

1 ms or 50 ms with damping

Static Pressure Effect:

+0.05% of URL <100 psi ranges

+0.1% of URL for 100 and 300 psi ranges

EMI Effect: ±1% URL @ 10 V/m from

20 to 500 MHz. Meets /SAMA

PMC-33-1C with cover in place and

electrical wiring in grounded conduit.

Approvals: UL/CUL

Hazardous Location: I/II, C, D

Non-incendive: I/II/A, B, C, D

Wetted Parts: 316 SS

Process Connection: 1/4 NPT internal,

1/2 NPT with optional adaptors

Fill Fluid: DC 200 silicone

Housing: Low copper aluminum, epoxy coated, NEMA 4X (IP66)

Electrical Connection: 1/2 NPTF conduit, with internal screw terminals

Weight: 2.9 kg (6.4 lb)

Compatible Meters:

DP41-E, DP25-E,

DP24-E, DP460,

DP3002-E and others

(see section D for complete selection)



MOST POPULAR MODELS HIGHLIGHTED!

To Order (Specify Model Number)

RANGE	MODEL NO.	PRICE	MAX WORK PRES	COMPATIBLE METERS*
0-17 to 0-100 inH ₂ O	PX771A-100WCDI	\$1005	2000 psi	iSeries, DP25B-E, DP41-E, DP460-E
0-50 to 0-300 inH ₂ O	PX771A-300WCDI	1005	2000 psi	iSeries, DP25B-E, DP41-E, DP460-E
0-4.2 to 0-25 psi	PX771A-025DI	1005	2000 psi	iSeries, DP25B-E, DP41-E, DP460-E
0-17 to 0-100 psi	PX771A-100DI	1005	2000 psi	iSeries, DP25B-E, DP41-E, DP460-E
0-50 to 0-300 psi	PX771A-300DI	1005	2000 psi	iSeries, DP25B-E, DP41-E, DP460-E

OPTIONS AND ACCESSORIES

-SUFFIX or MODEL NO.	PRICE	DESCRIPTION
-M3	\$175	3 1/2 digit LCD local indicator (FM approval not available with option)
PX771-AD	90	1 pair of stainless steel 1/2 NPT adaptors
PX771A-MB-KIT	65	2" pipe mounting bracket (order separately), flange mount
PX771A-MB-KIT-N	65	Neck mounting bracket kit (order separately)
OP-17	15	Reference Book: Measure for Measure

* See section D for compatible meters.

Comes with complete operator's manual.

Ordering Examples: PX771A-300WCDI, industrial transmitter with 0-50 to 0-300 inH₂O range, \$1005. PX771A-100WCDI, industrial transmitter with 0-17 to 0-100 inH₂O range, \$1005.

omega.co.uk[®]

Your One-Stop Source for Process Measurement and Control!

Freephone 0800 488 488 | International +44(0) 161 777 6622 | Fax +44(0) 161 777 6622 | Sales@omega.co.uk

www.omega.co.uk



UNITED STATES

www.omega.com

1-800-TC-OMEGA
Stamford, CT.

UNITED KINGDOM

www.omega.co.uk

Manchester, England
0800-488-488
+44-(0)161-777-6611

CANADA

www.omega.ca

Laval(Quebec)
1-800-TC-OMEGA

FRANCE

www.omega.fr

0800-466-342

GERMANY

www.omega.de

Deckenfronn, Germany
0800-8266342

BENELUX

www.omega.nl

0800-099-33-44



More than 100,000 Products Available!

• Temperature

Calibrators, Connectors, General Test and Measurement Instruments, Handheld Instruments for Temperature Measurement, Ice Point References, Indicating Labels, Crayons, Cements and Lacquers, Infrared Temperature Measurement Instruments, Recorders, Relative Humidity Measurement Instruments, PT100 Probes, PT100 Elements, Temperature & Process Meters, Timers and Counters, Temperature and Process Controllers and Power Switching Devices, Thermistor Elements, Probes and Assemblies, Thermocouples, Thermowells and Head and Well Assemblies, Transmitters, Thermocouple Wire, RTD Probes

• Flow and Level

Air Velocity Indicators, Doppler Flowmeters, Level Measurement, Magnetic Flowmeters, Mass Flowmeters, Pitot Tubes, Pumps, Rotameters, Turbine and Paddle Wheel Flowmeters, Ultrasonic Flowmeters, Valves, Variable Area Flowmeters, Vortex Shedding Flowmeters

• pH and Conductivity

Conductivity Instrumentation, Dissolved Oxygen Instrumentation, Environmental Instrumentation, pH Electrodes and Instruments, Water and Soil Analysis Instrumentation

• Data Acquisition

Communication Products and Converters, Data Acquisition and Analysis Software, Data Loggers Plug-in Cards, Signal Conditioners, USB, RS232, RS485, Ethernet and Parallel Port Data Acquisition Systems, Wireless Transmitters and Receivers

• Pressure, Strain and Force

Displacement Transducers, Dynamic Measurement Force Sensors, Instrumentation for Pressure and Strain Measurements, Load Cells, Pressure Gauges, Pressure Reference Section, Pressure Switches, Pressure Transducers, Proximity Transducers, Regulators, Pressure Transmitters, Strain Gauges, Torque Transducers, Valves

• Heaters

Band Heaters, Cartridge Heaters, Circulation Heaters, Comfort Heaters, Controllers, Meters and Switching Devices, Flexible Heaters, General Test and Measurement Instruments, Heater Hook-up Wire, Heating Cable Systems, Immersion Heaters, Process Air and Duct, Heaters, Radiant Heaters, Strip Heaters, Tubular Heaters